

MALEKKO

MUTE 4 MANUAL V.1

MALEKKOHEAVYINDUSTRY.COM

TABLE OF CONTENTS


SPECIFICATIONS	3
INSTALLATION	4
DESCRIPTION	5
DIAGRAM	6
WARRANTY	7

SPECIFICATIONS

FORMAT:	3HP EuroRack
DIMENSIONS:	35mm deep
MAX CURRENT:	20mA

INSTALLATION


1. Remove module from packaging
2. Power down your modular synthesizer and disconnect the power cable from the wall outlet.
3. Attach the included power cable to the module's power connector and connect the other end to the power distribution bus in your EuroRack synthesizer case:
4. Position the module on the mounting rails in your EuroRack case and screw down mounting screws. Power up! If your case does not turn on properly then you have installed the module incorrectly. Simply power down and make sure to follow the diagram when reconnecting the module.



DESCRIPTION

MALEKKO MUTE 4 is a 3hp module with 4 mutable channels for both audio and cv inputs, each with back-lit buttons for easy on-the-fly muting and a mixed output.

- Four channel unity mixer with latched mute switches
- Odd hp size
- Audio and CV signal support
- LED indicates mute “ON”



WARRANTY

This product is covered by the Malekko Heavy Industry warranty, for one year following the date of purchase. This warranty covers any defect in the manufacturing of this product. This warranty does not cover any damage or malfunction caused by incorrect use – such as, but not limited to, power cables connected backwards, excessive voltage levels, or exposure to extreme temperature or moisture levels.

The warranty covers replacement or repair, as decided by Malekko Heavy Industry. Please contact customer service via our website (www.malekkoheavyindustry.com) for a return authorization.